



SoftFit by Aplix®

Stretch laminates



Description

- Activated laminate of two strips of elastic film between two layers of high soft nonwoven
- Methods of attachment : gluing and bonding
- Basis weight : approx. 90 g/m² depending on width and construction
- Standard widths available : 60, 70, 75, 80, 120, 140, 150 and 160 mm

Key Benefits

- Elongation between 150% and 300%
- Soft touch and skin friendly
- Excellent tear off resistance
- Complies with Oeko-Tex® Standard Cass 1



Performances

Properties in Cross Direction	Mainline Typical values*	Premium Typical values*
Peak load	45 N	55 N
Elongation at 10N	Up to 60%	Up to 95%
Force relaxation after 10N Elongation	30 %	30 %
Percent Set after cycle of 10N Elongation	5 %	5 %
Elongation at break	Up to 200%	Up to 300%

* depending on test methods

Packaging

- Roll diameter : up to 1200 mm
- Roll length : 3000 lm in pancake / up to 22 000 lm in spool
- Core diameter : 6"

Shelf life and disposal information

- Stored in original packaging, away from sunlight, humidity and extreme temperatures
- Non recyclable product
- Disposal recommendation : the product must be entrusted to a waste processing company

The information contained in this document is for reference purposes only.
To obtain data suitable for use in technical specification, please contact your APLIX sales representative.